

*Jessica Dück, Nico Lastzka, •Sebastian Steinlechner,
Roman Schnabel and Karsten Danzmann*

Absorption Measurements on Silicon

Institute for Gravitational Physics, Leibniz Universität Hannover and
Max Planck Institute for Gravitational Physics (Albert Einstein Institute)
Callinstr. 38, 30167 Hannover, Germany

Max Planck Institut
for Gravitational Physics
AG Quantum Interferometry



Centre for Quantum Engineering
and Space Time Research




Leibniz Universität Hannover





Limits to gravitational-wave detection sensitivity

- Mid-frequency detection band limited by thermal noise
- Various noise sources are proportional to T or even T²
- Cryogenic techniques could reduce noise level drastically



Thermorefractive noise:

$$S_{TR}(f) \propto \beta^2 k_B T^2$$

Thermoelastic noise:

$$S_{TE}(f) \propto \alpha^2 k_B T^2$$



Substrate brownian noise:

$$S_{bulk}(f) \propto k_B T$$

Current test-mass material: fused silica

Fused silica

- + well known material
- + excellent optical properties
(Suprasil SV311: 0.25ppm/cm absorption @ 1064nm)
- high damping at low temperatures (Debye peak)
→ not suitable for cryogenic detectors




R. Nawrodt, PhD thesis



Silicon as a test-mass material

- Crystalline silicon available in large dimensions
450mm wafers will be introduced in upcoming years
- “Industrial quality” is already extremely pure



Uni Jena



wikipedia.de


www.squeezed-light.de






Properties of crystalline silicon: Q factor

- Q values exceeding 10^8 have been measured



R. Nawrodt, PhD thesis, Uni Jena




A. Schröter, PhD thesis, Jena




Properties of crystalline silicon: thermal conductivity

- Very high thermal conductivity:
> 10 W/(cm K) between 10K and 100K
(compare with $10^{-3}..10^{-2}$ W/(cm K) for glass,
3.9 W/(cm K) for copper @ 300K)




Properties of crystalline silicon: thermo-optic coefficient dn/dT

- Low thermo-optic coefficient $dn/dT \rightarrow$ low thermo-refractive noise



Properties of crystalline silicon: thermal expansion

- Thermal expansion higher than in fused silica at room temperature
- two zero crossings (18K and 125K) → vanishing thermoelastic noise




Thermoelastic noise:

$$S_{TE}(f) \propto \alpha^2 k_B T^2$$



Properties of crystalline silicon: Absorption coefficient




Hull, Properties of Crystalline Silicon, 1998

- Absorption coefficient orders of magnitude too high at 1064nm
- Transparency window between 1.4 μm and 2.5 μm
- No measurement data available in this window
- Measurements up to now mainly motivated by solar cell research, low absorption regime not interesting



Properties of crystalline silicon: Absorption coefficient



$\alpha \sim 10^{-8} / \text{cm}$ at 1550nm?



Keevers/Green, 1995

www.squeezed-light.de



Measurement of small absorption coefficients

Is the absorption coefficient α really as low as 10^{-8} /cm?

Directly measuring $I = I_0 e^{-\alpha x}$ is not sensitive enough



Measure effects of temperature change due to absorption: dn/dT

- Mirage method (thermal lensing)
- Our new method: “thermal kerr” effect
- Can only measure $\alpha \frac{dn}{dT}$, need to know various material constants
- High power needed for sufficient temperature increase
→ power built-up in high finesse cavity




Thermal Kerr effect

- High finesse cavity is scanned with varying speeds over one Airy peak (with PZT or by tuning the laser frequency)
- Both scan directions used



Measurement principle


- dn/dT introduces additional phase shift depending on scan direction, deforming cavity Airy peaks






Measurement principle

- Simulation program calculates time-dependant temperature profile inside cavity
- (almost) analytical model as presented by Hello & Vinet



First measurement results


- Tested measurement with ring mode-cleaning cavity ($F \sim 10000$), absorption coming from mirror coatings
- Very good agreement between experimental and simulated data
- Simulation parameters yield absorption coefficient





Setup for absorption measurements on Silicon


- Monolithic silicon cavity
 - 10cm diameter, 6.5cm length
 - Residual boron doping $< 10^{12} / \text{cm}^{-3}$
 - Mirror ROC 1m
 - estimated round-trip absorption 1ppm
- HR coated with SiO_2/Si
 - 170ppm transmission
 - Finesse $F \sim 18500$
- First measurements coming soon



What results do we expect?

- Residual doping will probably contribute most to the absorption:



$$\Delta \alpha = \frac{q^3 \lambda^2}{4 \pi^2 c^3 n \epsilon} \cdot \left(\frac{N_e}{m_{cc}^2 \mu_e} + \frac{N_h}{m_{ch}^2 \mu_h} \right) \approx 3 \cdot 10^{-7} / \text{cm}$$




- With sensible assumptions for laser power and coating properties, absorptions in the 0.01 ppm/cm regime ($10^{-8} / \text{cm}$) should be measurable

Current and upcoming work

- Currently validating measurement method
- First silicon measurements soon
- Confirm measurements with different method (Mirage?)



www.squeezed-light.de




 LASER ZENTRUM HANNOVER e.V.

- Up to 2W cw, singlemode, PM output commercially available
- LZH builds fibre amplifier with 10W output, 100W expected in 2-3 years

Measurement principle


- Fast scans are unaffected by absorption, ringing can be used to find correct cavity parameters (mirror reflectivities)





Temperature dependance of absorption coefficient

- Absorption coefficient drops with temperature





Monolithic mirrors

- T-structure gratings act as monolithic mirrors
- No coating thermal noise
- $R > 99\%$ demonstrated

