

T. Eberle, M. Mehmet, S. Steinlechner, H. Vahlbruch, A. Khalaidovski, K. Danzmann and R. Schnabel

Generation of Squeezed Light at 1064nm and 1550nm



Institute for Gravitational Physics, Leibniz Universität Hannover and
Max Planck Institute for Gravitational Physics (Albert Einstein Institute)
Callinstr. 38, 30167 Hannover, Germany

Max Planck Institut
for Gravitational Physics
AG Quantum Interferometry




Centre for Quantum Engineering
and Space Time Research



Leibniz Universität Hannover



Why Squeezed Light?








What is Squeezed Light?

Coherent State




Squeezed State



Uncertainty Principal: $\langle (\Delta \hat{X}_1)^2 \rangle \langle (\Delta \hat{X}_2)^2 \rangle \geq \frac{1}{16}$

www.squeezed-light.de




What do we need?

- A nonlinear crystal like
 - Lithium Niobate ($\text{MgO}:\text{LiNbO}_3$)
 - Periodically Poled Potassium Titanyl Phosphate (PPKTP)
- A pump beam at half the wavelength
- A resonator
 - To have a well defined mode

www.squeezed-light.de

Lithium Niobate ($\text{MgO}:\text{LiNbO}_3$):


- + type I phasematching
- + well-proven material with excellent results (10dB squeezing; audio band squeezing)
- very high phase matching temperature @ 1550nm (problems with stabilization, gradients, ...)



K. Betzler, Osnabrück

Periodically Poled Potassium Titanyl Phosphate (PPKTP):




- + quasi phasematching
- + higher nonlinearity
- + adjustable phase matching temperature
- grey-tracking issues (though maybe not at 775nm/1550nm)



www.squeezed-light.de




Squeezed Light Source



www.squeezed-light.de

Generation of Squeezed Light: Experimental Setup







Lasers at 1064nm and 1550nm

1064nm

Well known technology:

- Non planar ring oscillator (NPRO)
- Nd:YAG




1550nm

Technology: Erbium doped fiber


Commercially available:

- Reliable high power lasers for telecommunication purposes
- 1-2W polarization maintaining




www.squeezed-light.de

Results: Squeezing





Sideband frequency: 5 MHz

Results: Squeezing / Antisqueezing



Sideband frequency: 5 MHz


Squeezed




www.squeezed-light.de

Squeezed Light at 1064nm and 1550nm

1064nm



1550nm



Sideband frequency: 5 MHz

1550nm

- More squeezing possible with further investigation (e.g. lower losses)
- Audio frequencies feasible by applying same techniques as at 1064nm

www.squeezed-light.de

- Squeezed light can reduce shot-noise in interferometers
- Squeezed light is generated in nonlinear crystals: MgO:LiNbO₃ or PPKTP
- Squeezing is not only available at 1064nm but also at 1550nm:
 - 11.5dB @ 1064nm
 - 6.4dB @ 1550nm